

Flip Video Camera User Guide

The Basics



Getting Started

- Slide Power Switch down on the side of camera to power on and off.
- Note: The Flip camera will shut itself off after couple of minutes of inactivity.

To Record

- Press Record Button. Green ready changes to a red circle on upper left of screen showing recording status.
- Press Record Button again to stop recording.

To Zoom

- Press + and - buttons to zoom in and out.

View Recorded Video

- Press Play Button next to the Record Button to view recorded video.
- Use left and right Scroll Arrows on either side of the Record Button to scroll through saved clips.
- Press Play Button to play clip.

Delete Video

- Navigate to desired clip using Scroll Arrows and press Delete Button.
- Press Delete Button again at confirmation message to delete the clip.

Getting Video on your Computer (PC or Mac)

- Pull down USB Release, located opposite the Power Switch.
- Plug into USB port.
- The Flip Camera will appear in the Finder(Mac) or in My Computer(PC).